Purpose

Utility GOFLASH is used to determine whether or not the proper
conditions exist for the Flashboards Scheme to be needed.

Input Summary

No information in addition to general input is needed to use this
utility.

If this utility is executed by the RCL a flashboard scheme (FLASHBDS)
must be defined at the same level as the executed Utility GOFLASH.