Description

Subroutine DUSUP dumps parameters that define a water supply to a file
in the format that is used to define the parameters.

Calling Sequence

call dusup (po,iout)

Argument List

Argument	Input/ Output	Type	Dimension	Description
po	Input	R*4	*	Array containing parameters and computed water supply values for a location
iout	Input	I*4	1	Output device number