

#### V.2.4 FORECAST COMPONENT TIME SERIES EXTERNAL LOCATION INFORMATION

This Section describes the types of data files from which time series data can be read and to which time series data can be written by the Forecast Component.

For each of the data file types, the external location information that needs to be provided when defining the time series is described.

The following data file types can be read from or written to by the Forecast Component:

<u>Type</u>	<u>Description</u>
CARD	NWSRFS DATACARD Format File
FPDB	NWSRFS Forecast System Processed Data Base