

VI.3.6C-INFILE-GRID FILE FORMAT FOR PARAMETER GROUP: GRID

The Grid parameter group includes parameters used to define or redefine gridded threshold runoff values.

Input Data

The following input is used to define gridded threshold runoff.

Record	Field	Variable	Format	Columns	Description
--------	-------	----------	--------	---------	-------------

The following input is used to define the threshold runoff grid arrays for 1, 3 and 6-hour durations.

1	1	jdur	i4	1-4	Duration of runoff is different than default duration
	2		a4	5-8	Indicator for runoff data ' '
3		krow	i5	9-13	Row number of grid point on National HRAP scale
4		kol	1x,i4	15-18	Column number of grid point on National HRAP scale (or first column of identical runoff values in this row)
5		nok	i4	19-22	Number of columns in this row equal to runoff tro
6		tro	f6.3	23-28	Threshold runoff

Repeat record 1 as needed to define grid.

Sample Input

To define or redefine gridded threshold runoff values, the following input would be used:

1		310	420	1	0.340
3		310	420	1	0.450
6		310	420	1	0.900
1		310	421	1	0.380
3		310	421	1	0.500
6		310	421	1	1.050
1		280	415	1	0.400
3		280	415	1	0.580
6		280	415	1	0.880