

VI.5.3C-FCEEXEC-MOD-SACCO PROGRAM FCST FUNCTION FCEEXEC MOD SACCO

Purpose

MOD SACCO sets the specified Operation SAC-SMA contents, deficits or frozen ground index to the value entered.

Changes to UZTWC and LZTWC specified as deficits have precedent over changes specified as contents.

Format

Use Format B2 with one date on the command card.

```
.SACCO date [ FGROUP ]
identifier keyword value [ / opname ]
```

where date is the date for which the data value applies and must be less than or equal to Technique LSTCMPDY and must be within 12 hours before Technique STARTRUN or ENDRUN

keyword is:

- o UZTWC - upper zone tension water contents
- o UZFWC - upper zone free water contents
- o LZTWC - lower zone tension water contents
- o LZFSC - lower zone free secondary contents
- o LZFPC - lower zone free primary contents
- o ADIMC - additional impervious contents
- o UZTWD - upper zone tension water deficit
- o LZTWD - lower zone tension water deficit
- o FGIX - frozen ground index

value is the value

The keyword and value fields can be repeated.

Example

In this example Sacramento Model carryover is adjusted for several Segments.

```
.SACCO 1116
NWUM5 UZTWD 5 LZFSC 3 FGIX -2.
RAPM5 UZTWC 15 LZTWC 125
NULM5 LZFPC 15
```