

VI.3.4B-SYSTEM-DEBUG PROGRAM FCINIT COMMAND DEBUG

Purpose

Command DEBUG sets trace and debug variables.

Input Data

<u>Card</u>	<u>Field</u>	<u>Format</u>	<u>Contents</u>
1	1		'DEBUG'
2-n			See Section IX.3.3B-FSETBG for card format