

## VI.3.5-RUNCHECK PROGRAM ESPINIT COMMAND RUNCHECK

### Purpose

Command RUNCHECK checks if all time series used by ESP Segments have been defined.

### Input Summary

<u>Card</u>	<u>Format</u>	<u>Columns</u>	<u>Contents</u>
1		1-8	'RUNCHECK'
	2X,A8	11-18	Identifier type: 'CGROUP' = Carryover Group 'FGROUP' = Forecast Group 'SEGMENT' = Segment
	2X,A8	21-28	Identifier