

## VI.3.6 FLASH FLOOD GUIDANCE SYSTEM (FFGS) INITIALIZATION

This Section describes the programs used to initialize the Flash Flood Guidance System.

Section VI.3.6A [[Hyperlink](#)] describes program FFGUID Setup Menus used to define parameters for computation of Flash Flood Guidance values.

Section VI.3.6B [[Hyperlink](#)] describes program PRODGEN Setup Menus used to define parameters used for creation of Flash Flood Guidance products.

Section VI.3.6C [[Hyperlink](#)] describes the optional ASCII files used to define parameters.

Section VI.3.6D [[Hyperlink](#)] describes programs used to derive gridded threshold runoff.

Section VI.3.6E [[Hyperlink](#)] describes program ZGRID used to assign existing threshold runoffs by areas (i.e., zones, counties) to each HRAP bin within the boundary defined for the area.