

Purpose

Technique PRNTCGRP sets the Carryover Groups for which carryover data is to be printed.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Universal.

This Technique has 5 Arguments which are the Carryover Group identifiers.

The Global defaults for these Arguments are blank.

Form of Input

PRNTCGRP identifiers

where identifiers are the Carryover Group identifiers

Example

PRNTCGRP TULSARFC

Carryover for Carryover Group TULSARFC will be printed.