

Purpose

Technique RRSINMTS sets whether instantaneous miscellaneous time series data are to be printed.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

RRSINMTS(integer)

where integer is 1 or 0 specifying whether or not to print data

Example

RRSINMTS(1)

The instantaneous miscellaneous time series data will be printed for all stations that have time series written to the Processed Data Base.