

Purpose

Technique RRSINQTS sets whether instantaneous discharge time series data are to be printed.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

RRSINQTS(integer)

where integer is 1 or 0 specifying whether or not to print data

Example

RRSINQTS(1)

The instantaneous discharge time series data will be printed.