

Purpose

Technique RRSMNQTS sets whether mean discharge time series data are to be printed.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

RRSMNQTS(integer)

where integer is 1 or 0 specifying whether or not to print data

Example

RRSMNQTS(1)

The mean discharge time series data will be printed.