

Purpose

Technique WTEST24 sets whether estimated 24 hour precipitation totals are to be written to the Preprocessor Data Base.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

WTEST24(integer)

where integer is 1 or 0 specifying whether estimated 24 hour precipitation totals are to be written to the Preprocessor Data Base

Example

WTEST24(1)

The estimated daily totals will be written to the Preprocessor Data Base.