VI.5.3D-SYSTEM-PERMWRIT PROGRAM FCST HCL TECHNIQUE PERMWRIT

Purpose

Technique PERMWRIT sets whether time series are to be written to the ESP Permanent Time Series files for Function ESP.

Output time series not written to the permanent files will be written to the scratch file.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Nonuniversal.

Form of Input

PERMWRIT(integer)

where integer is 0 or 1 specifying whether or not to write time series to the ESP Permanent Time Series files

Example

PERMWRIT(1)

Time series will be written to the ESP Permanent Time Series files.