

VI.7-COPY PROGRAM REORDER COMMAND COPY

Purpose

Command COPY copies the specified data base from the old files to the new files.

Input Data

<u>Card</u>	<u>Field</u>	<u>Format</u>	<u>Contents</u>
1	1		'@COPY'
	2		'LHCL', 'ESP' or 'UPRM' <u>1/</u>

Notes:

1/ If 'LHCL' is specified the Hydrologic Command Language Local Data Base is copied.

If 'ESP' is specified the Extended Streamflow Prediction Parameter Data Base is copied.

If 'UPRM' is specified the User Parameter data file is copied.