

IX.3.0B-SYSTEM-HDFLTP SUBROUTINE HDFLTP

Description

Subroutine HDFLTP sets the defaults for Hydrologic Command Language [[Hyperlink](#)] Procedure definitions.

Calling Sequence

CALL HDFLTP (IGL, IF, NAME, IPASS, NNCARD)

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
IGL	Input	I*4	1	Global/Local indicator: -1 = Global 1 = Local
IF	Both	I*4	1	Field position
NAME	Input	A8	1	Procedure name
IPASS	Input	A4	1	Password
NNCARD	Input	I*4	1	Last card read