

IX.3.0B-SYSTEM-HDFUNC SUBROUTINE HDFUNC

Description

Subroutine HDFUNC runs the Hydrologic Command Language [[Hyperlink](#)] commands DEFINEL FUNCTION [[Hyperlink](#)] and commands DEFINEG FUNCTION [[Hyperlink](#)].

Calling Sequence

CALL HDFUNC (IGL, ISTAT)

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
IGL	Input	I*4	1	Global/Local flag: -1 = Global 1 = Local
ISTAT	Output	I*4	1	Status code: 0 = normal return 1 = error