

## IX.3.0B-SYSTEM-HDLLD1 SUBROUTINE HDLLD1

### Description

Subroutine HDLLD1 deletes one default value from a Hydrologic Command Language [[Hyperlink](#)] Local default for a Global definition.

### Calling Sequence

CALL HDLLD1 (ITYPE,NAME,NAMED,IDFREC,ISTAT)

### Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
ITYPE	Input	I*4	1	Definition type
NAME	Input	A8	1	Definition name
NAMED	Input	A8	1	Default name
IDFREC	Input	I*4	1	Local default record number
ISTAT	Output	I*4	1	Status code: 0 = normal return