

## IX.3.0B-SYSTEM-HDLLDR SUBROUTINE HDLLDR

### Description

Subroutine HDLLDR deletes a Hydrologic Command Language [[Hyperlink](#)] Local Definition Reference (LDR).

### Calling Sequence

CALL HDLLDR (NAME, ITYPE, ISTAT)

### Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
NAME	Input	A8	1	Local definition name
ITYPE	Input	I*4	1	Local Definition Reference record type
LDRARR	Input	NUMLDR	LDR	pointer array
NUMLDR	Input	I*4	1	Number of pointers in LDRARR
ISTAT	Output	I*4	1	Status code: 0 = normal return 1 = error