IX.3.3C-SYSTEM-FCFUTP COMMON BLOCK FCFUTP

<u>Purpose</u>

Common block FCFUTP contains the future precipitation usage indicator.

Listing

COMMON /FCFUTP/ IFPR

Description of Variables

<u>Variable</u>	<u>Type</u>	Dimension	Word <u>Position</u>	<u>Description</u>
IFPR	I*4	1	1	<pre>Future precipitation indicator: 0 = set all future precipitation values to zero regardless of what is read -1 = use precipitation values as read from file x = where x is the number of hours of future precipitation values to be used as read from file and 1<x<120; future="" of="" pre="" precipitation="" rest="" set="" the="" to="" values="" zero<=""></x<120;></pre>