Purpose

Common block PRDQPF contains information about whether QPF used when a
time series was written to the Processed Data Base.

Listing

COMMON /PRDQPF/ IRDQPF

Description of Variables

Variable	Type	Dimension	Word Position	Description
IRDQPF	I*4	1	1	QPF indicator: 0 = QPF not used -1 = QPF used for the entire forecast run 1-120 = number of hours of QPF used in forecast run