IX.4.5C-SYSTEM-SEGDATE PROGRAM FCINIT COMMAND SEGDATE

Command SEGDATE is used to date carryover for Segments and Forecast Groups not associated with Carryover Groups and modifies the following file:

File Name Action Taken

FCCARRY Write carryover dates to file

Message Output

The following messages are printed for each Segment's carryover that is dated; the first before the file writes take place and the second when the update is complete:

- *** BEGINNING FILE UPDATE FOR DATING SEGMENT XXXXXXXX.
- *** SUCCESSFUL FILE UPDATE FOR SEGMENT DATING.

Error Recovery

An abnormal termination during the execution does not prevent the further use of the files. However all dates may not have been written to the file and rerunning command SEGDATE after fixing the cause of the program failure will bring the files to and complete state.