

IX.7.1B-SYSTEM-EDSUP SUBROUTINE EDSUP

Description

Subroutine EDSUP is the editor used to add and change definitions for a water supply location.

Calling Sequence

call edsup (id,ipdv,is,po,istat)

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
id	Output	C*8	1	Identifier
ipdv	Output	I*4	1	Unit number of parameter file
is	Input	I*4	1	Edit mode for parameters: 1 = add 2 = change 3 = list
po	Both	R*4	*	Array containing parameters for a water supply location
istat	Output	I*4	1	Status code: 0 = no errors 1 = file not found 2 = end of file encountered 3 = error in reading file 4 = not used 5 = directory not found