

## IX.7.1B-SYSTEM-MGRID SUBROUTINE MGRID

### Description

Subroutine MGRID is used to maintain (add and change) gridded threshold runoff.

### Calling Sequence

call mgrid

### Argument List

None