

## IX.7.1B-SYSTEM-PINHED SUBROUTINE PINHED

### Description

Subroutine PINHED is input routine to define headwater parameters.

### Calling Sequence

call pinhed (id,istat)

### Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
id	Output	C*8	1	Identifier
istat	Both	I*4	1	Completion code: 0 = successful 1 = end of file or error 2 = invalid data type