

IX.7.2B-SYSTEM-SHEFPE SUBROUTINE SHEFPE

Description

Subroutine SHEFPE constructs SHEF [[Hyperlink](#)] codes including physical elements, duration code and type and source code for flash flood guidance and model carryover values.

Calling Sequence

```
call shefpe (type,mffg,iop)
```

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
type	Input	C*4	1	Data type
mffg	Input	I*4	1	Indicator for FFG PE code: 1 = use PF 2 = use PP
iop	Input	I*4	1	Operation Forecast System Operation number [Hyperlink]