

## IX.7.3B-SYSTEM-GETSUP SUBROUTINE GETSUP

### Description

Subroutine GETSUP fills common block wsparm with water supply guidance parameters from the po array.

### Calling Sequence

call getsup (po)

### Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
po	Input	R*4	*	Array containing parameters for a water supply location