

IX.7.4B-SYSTEM-EDWTID SUBROUTINE EDWTID

Description

Subroutine EDWTID edits basin weights and identifiers for headwater parameters.

Calling Sequence

call edwtid (kf,lin,lout,wt,aid,mx,ngrp)

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
kf	Input	I*4	1	Function: 1 = add 2 = change 3 = list
lin	Input	I*4	1	Unit number of input
lout	Input	I*4	1	Unit number of output
wt	Both	R*4	mx	Array of basin weights
aid	Both	C*8	mx	Array of identifiers
mx	Both	I*4	1	Number of identifiers in aid
ngrp	Both	I*4	1	Number of groups (identifiers)