

VI.3.6A-SETUP-WSUP PROGRAM FFGUID SETUP MENU FOR WATER SUPPLY
PARAMETERS

The Setup Menu for Water Supply is used to process Water Supply parameters.

An example of the menu is:

```
Water Supply Identifiers
1) FRAT1      2) KINT1      3) ELZT1
Select (a-add c-change d-delete l-list m-more p-previous):
Enter id:
```

Selection a-add or c-change

For selection 'a' or 'c' a prompt appears for the input source:

Enter Parameters (f-file [t]-terminal m-menu):

Selection f-file input

This selection prompts for a directory and filename of an ASCII file containing the parameters. The input data is described in Section VI.3.6C-FFGUID-WSUP.

Selection t-terminal input

This selection prompts for a water supply identifier:

Enter water supply id:

After entering a water supply identifier from the list, the water supply edit screen is displayed:

```
Edit Water Supply Parameters - id
(1) Description: Franklin TN
(2) Area: 0
(3) Boundary ID:
(4) Number of weighted areas: 1
    .00 FRAT1
Select (number or <return>-exit):
```

Selecting a number prompts for entering information for the selected parameter. Return exits to the list of identifiers.

Only 3 weighted areas are shown if Number of weighted areas is greater than 3. All weighted areas are displayed when this

parameter is selected for editing.

Selection d-delete

This selection displays the following prompt:

```
        Delete number:
            Identifier:
Are you sure (y or n):
```

By responding with the desired identifier number from the identifier list and the corresponding identifier, parameters for the identifier will be deleted. A response of 'n' will stop the deletion process and return to the identifier list.

Selection l-list

This selection displays the following prompt to write parameters to an ASCII file:

```
Directory and name of output file (<return>-exit)
Enter:
```

After entering the complete directory and filename, prompts appear for a range of identifier numbers from the identifier list:

```
List from ( 1):
        to (nnn):
```

where nnn is the number of identifiers defined

Parameters for the beginning identifier number through the ending identifier number are written to the specified file. The file can be edited and read as an input file when selection a-add or c-change is selected followed by selection f-file.

Selection m-more

This selection displays the next screen of identifiers when more identifiers exist beyond the current display.

Selection p-previous

This selection displays the previous screen of identifiers when more than 100 identifiers exists and the first identifier displayed is not identifier labeled 1.